


1. Zamek RS - roz. otworów 95/105/130mm
Rozstaw 95⁺:

RS400, RS400U	1B-5
RS500, RS500U	1B-5
RS520, RS520U, RS420, RS420U	1B-5

Rozstaw 105:

RS100, RS100U, RS100T	1B-3
RS200, RS200U, RS200T	1B-3
RS110, RS210, RS800	1B-4

Rozstaw 130:

RS130, RS140	1B-8
--------------	------

2. Zamek RS510, - rozstaw otworów 95mm	1B-7
3. Wkładka	1C-1,2
4. Nakrętka M22x1,5	-
5. Język 1-pkt bez ogranicznika	1C-10,11
6. Język 2-pkt, 3-pkt bez ogranicznika	1C-13,17
7. Pręt ø6	1C-3
8. Prowadnica metalowa ø6	1C-5
9. Pręt ø8	1C-3,4
10A. Prowadnica ø8 10B. Prowadnica RW	1C-5
11. Drzwi szafy	-
12. Rant szafy	-